

Warpath PRO Rigger

Quick Setup Guide

*complete build instructions: http://www.modelgasboats.com/media/kunena/attachments/62/MGBWarpathPROBuildingInstructions_R20151024.pdf



Key Setup Points

Your Warpath Pro Rigger is shipped with a few plastic shims (0.060")...these are to get you in the "ballpark".

We recommend that you fine tune the setup with additional shims as required. A shim kit such as this one from McMaster-Carr part # 97235K808 is very handy for this.

Here is a good starting point setup:

- ▶ Tub level to setup table
- ▶ Port sponson AOA of 3 deg
- ▶ Starboard sponson an AOA of 4 deg
- ▶ Round bottom strut flat on setup table level with the rear shoes (SM #SPDS-010-250MR)

- ▶ FULL LENGTH straight rudder (SM #SPDR-013-1SB)
- ▶ Ti-Titanium fin set with bottom edge level with the ride surface (setup table). NOTE: slight adjustments will be VERY noticeable.
- ▶ Port sponson parallel with the tub or 1/16 Toe-IN
- ▶ Starboard (turn fin) sponson Toe-IN 1/16 to 1/8"

Some props that have been found to work well on the Warpath Pro:

- ▶ 7316/2 PWW, 7318/2 PWW, **7217/2 PWW**
- ▶ 2718/2 - 2818/2 backcut round tip
- ▶ 2716 20* or 2918 20*
- ▶ CoCR TH1 3-blade